

Tuscarawas Valley Pioneer Power Association Inc.

Tractor Pull Rules

This is a Fun Pull with a \$10 Hook Fee

1. All tractors, regardless of year, that are exhibited at the Dover Steam Show are eligible to participate in this fun pull. No Prizes will be awarded.
2. A tractor can be pulled as many times as wanted, with different drivers, as long as tractor is weighted with each driver, all information is filled out completely and each pull is paid for. **Driver must be present at weigh in and sign the weight slip to be qualified to pull.**
3. All drivers must have and show their **T.V.P.P.A. Membership Card** at weigh in.
4. Maximum hitch height 18", with clevis. Center of axle point to hook point min of 18".
5. No cut tires allowed.
6. Speed limit is **5 MPH**.
7. The class in which a tractor and driver competes in is determined by their combined weight.
8. **Weights cannot be mounted any farther back than the rear axles, weights cannot be hung from the drawbar or 3pt hitch.**
9. All tractors and drivers must be ready when called
10. Once a class is started, no other entries will be accepted.
11. Weight in is from 3:00 to 6:00 PM, if for any reason you are going to be late, come see the **Scale Master** before the deadline. **Once scales are closed they will not be reopened.**
12. **All rulings of the Full Pulling Committee are final.**

Weight Classes and Pulling Order

A	UP TO 2750	H	5501 TO 6500
B	2751 TO 3000	I	6501 TO 7500
C	3001 TO 3200	J	7501 TO 8500
D	3201 TO 3800	K	8501 TO 9500
E	3801 TO 4500	L	9501 TO 10500
F	CRALWERS	M	10501 TO 11500
G	4501 TO 5500	N	11501 TO 12500